
尺寸:60x65mm(成品) 300x130mm(展开)

材质:105克双铜纸过油


颜色:CMYK

日期:20230625

封面










INSTRUCTIONS





⚠ Warm prompt


(1) Warrin prompt

1. Unlock / lock: when the product leaves the factory, in order to prevent mistouch, the "switch" has been locked, please double-click the "switch" to unlock before mode operation. By the same token, when you need to lock the "switch," double-click to lock it.


2. Color temperature adjustment: press the "switch" in the turn-on state, change the color temperature of the lamp body, and you can choose the current color temperature by letting go.

3. Memory setting: the product has a colour temperature memory function.

User manual of NexTool Acorn Light



Optional accessory, need to buy separately Lampshade assembly





② Insert the nail buckle into the round hole one by one



WARRANTY

×1 High ×1 OFF Type-C 7 Charge input: 5V == 0.4A Charge time: 2.5h±0.5h

C)

WARRANTY CARD

	Product Description	Name	Model#	
	User Information	Name	Phone	
		Address		
	Retailer Information	Address	Phone	
		Address/ Website		
		Sale date	Invoice#	